



TANK INSTALLATION GUIDELINES

Simplex[®]

Since 1990



Minimum 2 Feet



- Keep Tank Lid always closed to protect water from harmful contamination.
- Use Hole saw cutter to make holes in tank.

No Warranty on Overhead Tanks, if used for

- Underground Storage
- Construction Purpose
- Transportation Purpose
- Storage Purpose (Except Water)

Depreciation Period for the Warranty :

- Depreciation will be Charged @10 % per Annum.
- Replacement will be Ex-works.
- Transportation & GST Extra.

Customer Care No:-

+91 84848 81657

www.simplexplast.com

Follow Us on:

